






Elite Series Executive Quick Start Guide

Thank you for your purchase of the Eton Elite Series Executive Radio. Please use this document as a quick start guide for the product, and reference the product manual for more detailed instruction.

1. Powering the radio: You have three options to power your radio.
 - a. The included AC adapter
 - b. 4 AA alkaline batteries (not included)
 - c. 4 rechargeable AA batteries (not included). When using rechargeable batteries, you can charge them using the included AC adapter. You can set the charge time by holding the **F7 button** and select the charging time using the **TUNING DIAL**.

2. Quick button legend

	POWER Button		RDS Button
	FM/AIR BAND Button		ARROW Buttons
	LW/MW Button		PAGE TIME Button
	METER BAND Button		F1 – F7 Buttons

3. Basic Functions: To conserve battery life, the radio can still play while the display goes into standby mode.

Note, to use radio functions, the first step is to “wake” the radio by pressing the **POWER button** (or any button). The radio is in wake mode when the display is illuminated

4. Turning the radio On:
 - a. To turn the radio on, press the **POWER button** to wake up the display (if it's off).
 - b. Once the display is on, press the **POWER button** again to turn the radio on.
5. Turning the radio Off:
 - a. To turn the radio off, press the **POWER button** to wake up the display (if it's off).
 - b. Then, press the **POWER button** again to turn the radio off.
6. Selecting radio bands: The Eton Elite Executive features many different bands you can listen to. To select a band, make sure the radio is in wake mode by pressing the **POWER button**, and follow the below steps:
 - a. To select the FM band, press the **FM/AIRBAND button** once. The display will show FM as the selected band and then a FM frequency, such as 106.5 MHz.



- b. To select the AM band, press the **0 button**. The display will show AM as the selected band and then an AM frequency in kilohertz, such as 1050 kHz.
 - c. To select the VHF (Air) band, press the **FM/AIR BAND button** until the display shows AIR as the selected band (if you are in FM mode, you press the FM button once. If in another band, you press the button twice). The display will show VHF as the selected band and a VHF frequency.
 - d. To select the Shortwave (SW) band, press the **METER BAND button** to cycle through the shortwave bands. The display will show the shortwave meter in the main display (e.g. 15M, 13M and so on), and the frequency band will show AM
 - e. To select Single Side Band (SSB) mode, while in the shortwave band, press the **SYNC/SSB/RDS button** twice to activate SSB mode.
7. Selecting a Station: There are three ways to select a station.
- a. You can use auto-tuning by holding either of the **ARROW buttons** to automatically scan for stations.
 - b. You can also use manual tuning by rotating the **TUNING DIAL** to manually browse through frequencies.
 - c. For direct entry, type in the exact frequency using the numeric buttons. For FM, type the station on the **NUMERIC KEYPAD**, such as 106.5, and then press the **FM/AIR BAND button** to confirm. For AM, type the station, such as 1050, and then press the **LW/MW BAND button** to confirm, and so on.
8. Using the Auto-Tune Function (FM): To auto-tune and save stations in the FM band, first go to the FM band by pressing the **FM/AIR BAND button**. Hold either of the **ARROW buttons** to start scanning through available stations. The radio will automatically scroll and save the stations. Once completed, press either of the **ARROW buttons** to scroll through the pages of saved presets. Use the **F1-F7 buttons** to select the stored stations from each page. Note: if you see "MONO" on the screen, press the **PAGE TIME button** to scroll through page view.
9. Setting the Time: To set the clock, turn off the radio. Press and hold the **PAGE/TIME button** until the hour digits start flashing. Use the **tuning dial** to set the correct hour. Press the **PAGE/TIME button** again to set the minutes and adjust them using the tuning dial. Press the **PAGE/TIME button** again to select RDS mode (using the **TUNING DIAL**), once more to select 12 or 24 hours (using the **TUNING DIAL**), and then a final time to confirm all.
10. Setting the Sleep Timer: To set the sleep timer, turn on the radio. Enter the desired sleep time using the **NUMERIC KEYPAD**, for example, 30 for 30 minutes. Press the **POWER button** again. The sleep icon and "SLEEP - XX" (where XX is the number of minutes) will display on the screen.
11. Turning On and Using RDS: To use Radio Data System (RDS) on FM stations that support it, first turn on the radio and switch to the FM band. When you tune to an FM station with RDS, an RDS icon will appear on the display. Press the **SYNC/SSB/RDS button** to toggle through RDS information such as the station name (PS), program type (PTY), radio text (RT), and time/date information (DATA).

Thanks again for your purchase of the Eton Elite Series Executive Radio. Happy Listening!